


65mm

100mm

NIIMBOT

# Product Manual

Smart Label Printer



NIIMBOT D110\_M

**Notice:** If the device cannot be turned on, please charge for one hour.

Wuhan Jingchen Intelligent Identification Technology Co., Ltd.  
Support Email : service@niimbot.com  
Official Website : www.niimbot.com  
Manufacturer's Address : No. 5, Creative Workshop, Creative World, Yezhihu West Road, Hongshan District, Wuhan, China

© 2024 NIIMBOT. All Rights Reserved.  
NIIMBOT is a brand under Wuhan Jingchen Intelligent Identification Technology Ltd.


单位: mm 印刷位移公差±1

名称	说明书-D110_M-英文-80g双胶纸	页数	16P	<b>NIIMBOT精臣</b>		
尺寸	65*100mm±1mm	材质	80g双胶纸	日期	2024.03.07	备注:
装订	骑马钉	印刷	单色印刷	料号	33010263502	
工艺	/	版本	V1.1	设计	刘楠	

**NIIMBOT**

# Product Manual

**Smart** Label Printer



**Notice:** If the device cannot be turned on, please charge for one hour.

**Wuhan Jingchen Intelligent IdentificationTechnology Co., Ltd.**

Support Email : [service@niimbot.com](mailto:service@niimbot.com)

Official Website : [www.niimbot.com](http://www.niimbot.com)

Manufacturer's Address : No. 5, Creative Workshop, Creative World, Yezhihu West Road, Hongshan District, Wuhan, China

© 2024 NIIMBOT. All Rights Reserved.

NIIMBOT is a brand under Wuhan Jingchen Intelligent Identification Technology Ltd.

**NIIMBOT D110\_M**






Scan the QR code to view tutorial videos

# 01

## Package Contents




Smart Label Printer \*1



Label Paper Roll \*1




USB Type-C Cable \*1




Product Manual \*1

# 02


## Installation



- 1 Press and hold the Power button for three seconds to switch on the printer.



- 2 Slide left to open the compartment.



※ Note: The print paper should be installed into the compartment with the print side facing down.

- 3 Fit the print paper into the compartment with the print side facing down, and the first label paper sticking out of the tear-off opening, and then close the compartment.

# 03

## Installing App

- 1 Before using the printer, please install the NIIMBOT app from Google Play or the App Store.



**NIIMBOT**  
Design & Print APP  
easy to download and use



※ More information available on the NIIMBOT app.

Sign in to NIIMBOT ▶ Me ▶ Help Center ▶ Hardware

- 2 Get the NIIM app for more label designs for homes.



**NIIM**  
Design & Print APP  
easy to download and use



# 04

## Connecting and Printing

- 1 After downloading the APP, make sure your phone's Bluetooth is on.
- ※ Note: For Android phones, location permission must be granted.



Turn on Bluetooth


- 2 Open the APP, search and connect to the device through Bluetooth.
- ※ Notice: If a PIN code is required, input 0000 or 1234.
- 3 After connecting, enter the "Canvas" page to edit.

## Special Notes

Images of products, accessories, and the app in this manual are for illustrative purposes only and may be different from actual products. Products are subject to change without prior notice.

# 05

## Product Description




## Button Function Description

Operation	Function
Long Press for 2-3 Seconds	Switch on/off
Press Once	Set to "Do not feed paper", "Print Current Time", or "Print History" in the APP
Double-press	Print test page

## Indicator Light Description

Color	Status	Description
Blue	Solid On	Powered on, but not connected
	Blinking Fast	Firmware upgrading
Green	Solid On	Bluetooth connected
	Blinking Fast	Printing
Red	Solid On	Device abnormality



## Power Indicator Description

Color	Status	Description
White	Blinking Slowly	Charging
	Solid On	Fully Charged and Connected to Power
	Blinking Fast	Low Battery

# 06

## Specifications

Product	Label Printer	Model	NIIMBOT D110_M
Dimensions	97*75*30mm	Weight	149g
Charging Time	3 - 4 hours	Input	5V DC, 1A
Battery Capacity	1500mAh	Printing Method	Thermal printing
Printing Resolution	203dpi	Printing Width	12mm
Connectivity	Bluetooth	Charge	Type-C
Transmit Power	4dBm(Maximum)	Operating Temperature	5°C - 40°C

# 07

## Safety Precautions

Please read all the instructions and warnings in this manual carefully before using this product to ensure the proper functioning of the device and your safety.

### \*Warnings



Don't disassemble the product without authorization. Disassembled products cannot be returned or exchanged.



Do not wipe the product with corrosive chemicals or cleaning agents.



Do not use the product near places with flammable products such as gas stations or fuel depots.

1. Please keep the product and accessories out of the reach of children or they must be used under the supervision and guidance of a guardian;
2. Turn off the power immediately when water gets into the product;
3. Turn off the power immediately in case of any product malfunction;
4. If you want to use a power adapter, always use one that is safe, regulatory-compliant, and compatible;

5. Do not disassemble the product to replace the battery. Improper operation may cause an explosion;
6. The battery contains special protection circuit and device, please do not disassemble the battery without authorization, otherwise it may cause a short circuit or leakage. If electrolyte gets into your eyes, flush with water immediately and seek medical help;
7. Do not expose the product and the power adapter to high temperature or high humidity. Do not put them in water, otherwise a short circuit may occur and the battery may heat up, smoke, deform, damage, or even explode;
8. If smoke or smell comes from the product or the power adapter, please unplug the power adapter immediately and avoid any burns.


### **\*Important**

1. Please use NIIMBOT label paper to prevent print quality issues or printhead damage;
2. The product comes with a built-in rechargeable battery. Do not throw it into fire or heat it. Do not charge, use or store it in a hot place, as this may cause overheating, fire or explosion.

3. Please purchase our product models designed for specific your country or region through the official NIIMBOT store or NIIMBOT authorized channels. Purchasing a NIIMBOT product through an unauthorized source may expose you to piracy risks, compatibility issues with your local environment, or other factors that could affect the product's proper functionality. Additionally, NIIMBOT may not be able to provide support for issues related to products obtained through unauthorized channels.

# 01

## Paket İeriđi




Akıllı Etiket Yazıcı \*1



Etiket Kađıdı Rulosu \*1




USB Type-C Kablosu \*1




rn Kılavuzu \*1

# 02


## Kurulum



- 1 Güç düğmesini üç saniye basılı tutun.  
Yazıcıyı açın.



- 2 Bölme için sola kaydırın.



※ Not: Baskılı kağıt, baskılı yüzü aşağı bakacak şekilde bölmeye yerleştirilmelidir.

- 3 Baskılı kağıdı, baskılı yüzü aşağı bakacak şekilde bölmeye yerleştirin ve ilk etiket kağıdı yırtılabilir açıklıktan dışarı çıkacak şekilde konumlandırın, ardından bölmeyi kapatın.

# 03

## Uygulama Nasıl Yüklenir

- 1 Yazıcıyı kullanmadan önce lütfen Google Play veya App Store'dan NIIMBOT uygulamasını yükleyin.



**NIIMBOT**

Tasarım ve Baskı  
Uygulaması  
İndirmesi ve  
kullanımı  
kolaydır.



※ Daha fazla bilgi NIIMBOT uygulamasında mevcuttur.

NIIMBOT'a giriş yapın

▶ Me

▶ Yardım Merkezi

▶ Donanım

- 2 Ev kullanımında daha fazla etiket tasarımı için NIIM uygulamasını indirin.



**NIIM**

Tasarım ve Baskı  
Uygulaması  
İndirmesi ve kullanımı kolaydır.



# 04

## Baęlantı ve Yazdırma

- 1 Uygulamayı kapattıktan sonra telefonunuzun Bluetooth'unun açık olduęundan emin olun.

✘ Not: Android telefonlar için konum izni verilmesi gerekmektedir.



Bluetooth'u açın



- 2 Uygulamayı açın, cihazı arayın ve Bluetooth üzerinden baęlantı kurun.

✘ Uyarı: PIN kodu gerekiyorsa, 0000 veya 1234 girin.


- 3 Baęlantı kurulduktan sonra, düzenleme yapmak için "Etiket" sayfasına girin.

## Özel Notlar

Bu kılavuzdaki ürün, aksesuar ve uygulama görselleri yalnızca örnek amaçlıdır ve gerçek ürünlerden farklı olabilir. Ürünler önceden haber verilmeksizin değiştirilebilir.

# 05

## Ürün Açıklaması




## Düğme İşlevi Açıklaması

Operasyon	İşlev
Uzun basın 2-3 Saniye	Açma/kapama
Bir kez basın	Uygulamada "Kağıt beslemeyin", "Geçerli Saati Yazdırın" veya "Geçmişini Yazdırın" seçeneklerinden birini ayarlayın.
Çift basın	Test sayfasını yazdır

## Gösterge Işıığı Açıklaması

Renk	Durum	Tanım
Mavi	Açık	Çalışır durumda, ancak batılı de il.
	Hızlı Yanıp Sönen	Yazılım güncelleniyor
Yeşil	Açık	Bluetooth batılı
	Hızlı Yanıp Sönen	Baskı yapıyor
Kırmızı	Açık	Cihazda anormallik



Güç Göstergesi

## Güç Göstergesi Açıklaması

Renk	Durum	Tanım
Beyaz	Yavaş Yanıp Sönen	Arj oluyor
	Açık	Tamamen arj edilmiş ve güç batılı.
	Hızlı Yanıp Sönen	Pil seviyesi düşük

# 06

## Teknik Özellikler




Ürün	Etiket Yazıcısı	Model	NIIMBOT D110_M
Ölçüler	97*75*30 mm	Ağırlık	149g
Şarj süresi	3 - 4 saat	Giriş	5V DC, 1A
Pil Kapasite	1500mAh	Baskı Yöntem	Termal baskı
Baskı Çözünürlük	203 dpi	Baskı Genişlik	12 mm
Bağlantı	Bluetooth	Şarj	C Tipi
İletim Gücü	4dBm (Maks)	Çalışm Sıcaklık	5°C - 40°C

# 07

## Güvenlik Önlemleri

Ürünün düzgün çalışmasını sağlamak için lütfen kullanmadan önce bu kılavuздaki tüm talimatları ve uyarıları dikkatlice okuyun. cihazınız ve güvenliğiniz.

### \*Uyarılar

 <p>Ürünü yetkisiz olarak sökmeyin. Demonte edilmiş ürünler iade edilemez veya de i tirilemez.</p>	 <p>Ürünü a ındırıcı kimyasallar veya temizlik maddeleriyle silmeyin.</p>	 <p>Ürünü benzin istasyonları veya yakıt depoları gibi yanıcı maddelerin bulundu u yerlerin yakınında kullanmayın.</p>
---	---	---

1. Lütfen ürünü ve aksesuarlarını çocukların eri emeyece i yerde saklayın. Bunlar, bir vasinin gözetimi ve rehberli i altında kullanılmalıdır;
2. Ürünün içine su girdi inde gücü hemen kapatın;
3. Üründe herhangi bir arıza olması durumunda gücü derhal kapatın;
4. Güç adaptörü kullanmak istiyorsanız, her zaman güvenli, yönetmeliklere uygun ve uyumlu bir adaptör kullanın; patlamaya neden olabilir;
5. Pilini de i tirmek için ürünü sökmeyin. Yanlı kullanım sonucu hasar olu abilir.

6. Pili, özel bir koruma devresi ve cihazı içerir; lütfen yetkisiz olarak pili sökmeyin, aksi takdirde kısa devreye veya sızıntıya neden olabilir. Elektrolit gözünüze kaçarsa, derhal suyla yıkayın ve tıbbi yardım alın;
7. Ürünü ve güç adaptörünü yüksek sıcaklıkta veya yüksek neme maruz bırakmayın. Suya koymayın, aksi takdirde kısa devre meydana gelebilir ve pil ısınabilir, duman çıkarabilir, deforme olabilir, hasar görebilir veya hatta patlayabilir;
8. Üründen veya güç adaptöründen duman veya koku gelirse, lütfen güç adaptörünü hemen fi ten çekin ve yanıklardan kaçınin.

### \*Önemli

1. Baskı kalitesi sorunlarını veya baskı kafası hasarını önlemek için lütfen NIIMBOT etiket kağıdı kullanın;
2. Pil yeterli güç sağlayamadığında lütfen ürünü kullanmayı derhal bırakın; Ürün dahili şarj edilebilir bir pil ile
3. birlikte gelir. Ateşe atmayın veya ısıtmayın. Aşırı ısınmaya, yangına veya patlamaya neden olabileceğinden, ürünü sıcak bir yerde şarj etmeyin, kullanmayın veya saklamayın.