


DREO

Smart Air Purifier
Akıllı Hava Temizleyici
338S

USER MANUAL
Kullanım Kılavuzu



”

Thanks for Choosing **DREO!**

Your support means the world to us.
We hope you enjoy our product as much
as we did creating it.

LANGUAGES

English ————— 1-13

Türkçe ————— 14-26

CONTENTS

01

KNOWING YOUR
APPLIANCE

1

02

USING YOUR
APPLIANCE

2-6

03

CONNECTING TO
YOUR APPLIANCE

7

04

CLEANING AND
MAINTENANCE

8-10

05


TROUBLESHOOTING

11-13

KNOWING YOUR APPLIANCE

01


Package Contents



Filter



3x Aroma Pads
(1 Pre-installed)




USING YOUR APPLIANCE

02


Before Use

1




Put it upside down. Rotate the bottom cover counterclockwise to unlock and take the cover off.

2




Remove the filter from its packaging, then put the filter into the appliance.

3



Rotate the bottom cover clockwise to lock back in place (you will hear a distinctive sound when locked).

4



Return to upright position on a flat, stable, and clear surface. Plug the appliance into the power outlet.



CAUTION

Risk of fire. Make sure the plastic packaging has been removed from the filter before operating this appliance.

Control Panel



Power Button

- Turn power on/off.



Purifying Speed Button

- Adjust purifying speed across 1-4 levels & Turbo (Turbo Mode will show up as level "H").



Timer Button

- Set a timer (0-12 hours) to turn the appliance on/off.
Note: The timer hour is shown on the LED display.



Auto Mode Button

- Purify and adjust purifying speed automatically based on air quality conditions.
- Long press for 5 seconds to start WiFi connection settings.



LED Light Button

- Turn the LED light on/off for the display, control panel, or air quality indicator.
- Long press for 5 seconds to reset the filter change reminder after replacing the filter.



Sleep Mode Button


- Touch to purify the air at the most silent power setting (display auto-off in 5s).
- Long press for 3 seconds to activate/deactivate the child lock function (display will show "LC").
- Press  or  to exit Sleep Mode.

Note: Long press  and  for 10 seconds to enter Low Power Standby Mode and turn off WiFi. To exit, long press  for 5 seconds, and WiFi connection will restart.

LED Display

Constantly monitor the air quality in your room with the comprehensive and intuitive monitor display.


Note: You can turn off the LED display and lights using the  button or through the DREO app.



Air Quality Indicator Light


Light Color	Air Quality Level
 Blue	Excellent
 Green	Good
 Orange	Moderate
 Red	Poor

Note: The Air Quality Sensor detects PM 2.5 particles but cannot detect odors. If you feel that the indoor air odor is relatively strong, it is recommended to manually switch to the highest purifying speed.



Adding Essential Oil

1




Pull out the aroma pad tray.

2




Make sure the aroma pad is in the tray.

3



Add the essential oil to the aroma pad.

4



Put the aroma tray back in place.

Additional Features



Child Lock

- Long press  for 3 seconds to activate/deactivate the child lock function.
- When activated, the display will show , and all the buttons on the appliance will be locked.



On/Off Timer

When the appliance is ON/OFF, touch the timer button repeatedly to set a timer (from 0-12H) for the appliance to turn ON/OFF.



Memory

If the appliance is turned OFF or disconnected from power, it will operate under the previous settings (except the Timer setting) when it is turned ON again.



Firmware Update

Check the firmware version on the DREO app and update regularly for the appliance to work more efficiently.



- Display will show "UP" during the update process.
- Do not operate until the update is completed.



Display Auto Off

Display turns off after 5 seconds in Sleep Mode. Wake up the display with any button.

Getting the Most Out of This Appliance



1. Keep the doors and windows closed when the air purifier is on.
2. Do not block the air openings and keep away from curtains or walls.
3. Maintain and replace the filter on a regular basis for maximum efficiency.

CONNECTING TO YOUR APPLIANCE

03



Before connecting the appliance to your mobile device, please scan the QR code on the left or go to the app store and search “**DREO**”, then select and download the app.



Look for “**Smart Air Purifier 338S**” when connecting your new appliance.



You can use the DREO app to connect your appliance to **Amazon Alexa** or **Google Home**. Please follow the in-app instructions to set up your voice assistant.

NOTE: You must create a DREO account to access voice assistants.

- 1 Launch DREO and sign in or create an account by following in-app instructions.
- 2 Enable Bluetooth on your mobile device and plug in your appliance.
- 3 Hold (A) for 5 seconds to start WiFi connection settings.
(Tip: The WiFi icon  will keep flashing when pairing.)
- 4 Tap+ **Add Device** and select **Smart Air Purifier 338S**.
- 5 Follow in-app instructions to complete WiFi connection.
- 6 You're now ready to control the appliance on your app.
(Tip: To restart connection settings, hold (A) again for 5 seconds)


CLEANING AND MAINTENANCE

04

Replacing the Filter


The filter life is measured by the air purifier's algorithm which is based on the working mode, fan speed, run time, and indoor air quality. It's recommended to replace the filter every 6-8 months or when the filter change reminder alerts.

1




The filter change reminder will flash when the filter needs to be replaced. Turn off and unplug the air purifier.

2




Rotate the bottom cover counterclockwise to unlock then take the cover off.

3




Remove the plastic packaging.

4




Remove the old filter, then put the new filter in place.

5



Rotate the bottom cover clockwise to lock back in place (you will hear a distinctive sound when locked).


6



Return to upright position and long press the  for 5 seconds until it beeps, to reset the filter change reminder.


Cleaning the Inside & Outside

1




Unplug the air purifier before any cleaning and maintenance.

2



Remove the filter and clean the inside with a dust vacuum.


3



Wipe clean the housing with a dry, soft, non-abrasive cloth.

Cleaning the Filter


- For optimal use, the outer pre-filter can be cleaned with a soft, dry brush once every 2-4 weeks.
- Keep away from water and humid areas. Moisture will allow mold to grow.



Cleaning the Aroma Pad Tray


RECOMMENDED ONCE A WEEK

1



Pull out the aroma pad tray.

2



Rinse with water and place back into the base.

Related to Filter

Where can I buy a new filter?

To purchase new filters, please contact our customer service.

I changed the filter, but the Filter Change Reminder is still on.

The Filter Change Reminder will not automatically reset. Please press and hold  to reset the reminder, the indicator will turn off after reset.

The Filter Change Reminder has not turned on for a long period of time.

There are several factors that can impact the filter life, including the indoor air quality level, length of operation and particle density in the air. If your room has a better air quality level and/or you don't use your air purifier often, the reminder will take longer to light up.

Related to Use

Why is my air purifier not working?

Check if the power is connected, the power cord is damaged, or the electrical outlet is powered.

The airflow from my air purifier is too weak.

- Make sure that there is enough space around the air purifier.
- Check if the filter packaging has been removed.
- Fan speed will be low when auto mode is switched on and air quality is good. Try to switch to higher speed.
- Replace the filter if the filter is clogged and overloaded.

My air purifier doesn't improve the air quality.

- Check if the filter packaging has been removed.
- Make sure the windows are closed as polluted air may continue coming in from outside of the windows.
- The overloaded filter will make the fan work harder to pass the air through. Consider replacing the filter if it is clogged.
- Do not place in crowded areas and corners.
- Check if air outlet and inlet are obstructed.

Why is my air purifier making a loud noise?

- Switch the air purifier to sleep mode or lower purifying speeds.

Why is the Air Quality indicator is always red?

- It's recommended to move the appliance to a different location, replug it, and check the indicator light again. If the issue persists, please contact our Customer Support.

The odor in the room is very strong, but the Air Quality Indicator is only green or blue.

- The Air Quality Sensor detects PM 2.5 particles but cannot detect odors. If you feel that the indoor air odor is relatively strong, it is recommended to manually open the highest purifying speed.

Why is the Air Quality indicator always blue?

- The Air Quality sensor reports the presence of airborne particles, but it cannot detect gas. Please make sure there is no gas contamination inside your room.

Why is my air purifier making an unusual noise?

- Make sure the air purifier is operating on a flat, stable surface.
- If the unusual noise still exists, there may be external objects blocking the air openings. Please contact our customer support.

Why does my air purifier produce an unpleasant smell?

- During the initial few days, new air purifiers produce a plastic smell which is normal and will dissipate eventually.
- Do not add essential oils or diffusers into the air purifier or use in a excessively humid area. Humidity will cause mold to grow.
- If the filter has absorbed pollutants to its maximum capacity, then the smell may come from the dirty filter. Please replace the filter when necessary.

If your problem is not listed or still persists, contact our Customer Support (see page 27).

İÇERİK

01

CİHAZINIZI
TANIMA

14

02

CİHAZINIZI
KULLANMA

15-19

03

CİHAZINIZA
BAĞLAMA

20

04

TEMİZLİK
VE BAKIM

21-23

05


SORUN
GİDERME

24-26

CİHAZINIZI TANIMA

01

Paket İçeriği




Filtre



3 x Aroma Padi
(1 Önceden yüklenmiş)

Kullanım
Kılavuzu

ÖNEMLİ
GÜVENLİK
TALİMATLARI




CİHAZINIZI KULLANMA

02


Kullanımdan Önce

1




Baş aşağı koyun. Kapağı açmak ve çıkarmak için alt kapağı döndürün.

2




Filtreyi ambalajından çıkarın ve ardından filtreyi geri takın.

3



Alt kapağı saat yönünde döndürerek yerine oturtun (kilitlendiğinde belirgin bir ses duyacaksınız).

4



Düz, sabit ve temiz bir yüzeyde dik konuma getirin, cihazı prize takın.



İKAZ

Yangın riski. Bu cihazı kullanmadan önce filtredeki plastik ambalajın çıkarıldığından emin olun.

Kontrol Paneli



Güç Düğmesi

- Gücü açma/kapatma



Arındırma Hızı Düğmesi

- Arıtma hızını 1-4 kademesi ve Turbo arasında ayarlayın. (Turbo Modu "H" seviyesi olarak görünecektir.)



Zamanlayıcı Düğmesi

- Cihazı açmak veya kapatmak için bir zamanlayıcı (0-12 saat) ayarlayın.
- Not: Zamanlayıcı saati LED ekranda gösterilir.



Otomatik Mod Düğmesi

- Hava kalitesi koşullarına göre otomatik olarak arındırın ve arındırma hızını ayarlayın.
- WiFi bağlantı ayarlarını başlatmak için 5 saniye boyunca uzun basın.



LED Işık Düğmesi

- Ekran, kontrol paneli veya hava hava kalitesi göstergesi için LED ışığını açın/kapatın.
- Filtreyi değiştirdikten sonra filtre değiştirme hatırlatıcısını sıfırlamak için düğmeye 5 saniye boyunca basılı tutun.



Uyku Modu Düğmesi


- En sessiz güç ayarında havayı temizlemek için dokunun (ekran 5 saniye sonra otomatik olarak kapanır).
- Çocuk kilidi işlevini etkinleştirmek veya devre dışı bırakmak için düğmeye 3 saniye boyunca basılı tutun (ekranda "LC" yazısı görünecektir).
- Uyku Modundan çıkmak için  veya  düğmesine basın.

Not: Düşük Güç Bekleme Moduna girmek ve WiFi'yi kapatmak için  ve  tuşlarına 10 saniye boyunca uzun basın. Çıkmak için  tuşlarına 5 saniye boyunca uzun basın, WiFi bağlantısı yeniden başlayacaktır.

LED Ekran

Kapsamlı ve sezgisel monitör ekranıyla odanızdaki hava kalitesini sürekli olarak izleyin.


Not:  düğmesini veya DREO uygulamasını kullanarak LED ekranını ve ışıklarını kapatabilirsiniz.



Hava Kalitesi Gösterge Işığı


Işık Rengi	Hava Kalitesi Seviyesi
 Mavi	Mükemmel
 Yeşil	İyi
 Turuncu	Orta
 Kırmızı	Zayıf

Not: Hava Kalitesi Sensörü PM 2.5 parçacıklarını algılar ancak kokuları algılayamaz. İç mekan hava kokusunun nispeten güçlü olduğunu düşünüyorsanız, en yüksek arıtma hızını manuel olarak açmanız önerilir.



Esansiyel Yağ Ekleme

1




Aroma pedi tepsideyi çekip çıkarın.

2




Aroma pedinin tepside olduğundan emin olun.

3



Aroma pedine esansiyel yağ ekleyin.

4



Aroma tepsisini yerine geri koyun.

Ek Özellikler



Çocuk Kilidi

- Çocuk Kilidi işlevini etkinleştirmek/devre dışı bırakmak için  tuşlarına 3 saniye boyunca uzun basın.
- Etkinleştirildiğinde ekranda  gösterilir ve ısıtıcıdaki tüm düğmeler kilitlenir.



Zamanlayıcı

- Cihaz AÇIK/KAPALI olduğunda, cihazın AÇIK/KAPALI konuma geçmesi için bir zamanlayıcı (0-12H) ayarlamak üzere zamanlayıcı düğmesine tekrar tekrar dokunun.



Bellek

Isıtıcı KAPALI konuma getirilirse veya güç bağlantısı kesilirse, tekrar AÇIK konuma getirildiğinde önceki ayarlarla (Zamanlayıcı ayarı hariç) çalışır.



Üretici Yazılımı Güncellemesi

DREO uygulamasında üretici yazılımı sürümünü kontrol edin ve cihazın daha verimli çalışması için düzenli olarak güncelleyin.

-  Güncelleme işlemi sırasında ekranda "UP" yazısı görünecektir. Güncelleme tamamlanana kadar çalıştırmayın.



Ekran Otomatik Kapatma

Ekran, Uyku Modunda 5 saniye sonra kapanır. Ekranı herhangi bir düğmeyle uyandırın.

Bu Cihazdan En İyi Şekilde Yararlanma



1. Hava temizleyici açıkken kapıları ve pencereleri kapalı tutun.
2. Hava açıklıklarını kapatmayın ve perdelerden veya duvarlardan uzak tutun.
3. Maksimum verimlilik için filtreyi düzenli olarak bakımını yapın ve değiştirin.

CİHAZINIZA BAĞLAMA

03



Cihazı mobil cihazınıza bağlamadan önce lütfen soldaki QR kodunu tarayın veya uygulama mağazasına gidip "DREO" yu arayın, ardından uygulamayı seçin ve indirin.



Yeni cihazınızı bağlarken "Smart Air Purifier 338S" arayın.



Cihazınızı **Amazon Alexa** veya **Google Home**'a bağlamak için DREO uygulamasını kullanabilirsiniz. Sesli asistanınızı ayarlamak için lütfen uygulama içi talimatları izleyin.

NOT: Sesli asistanlara erişmek için bir DREO hesabı oluşturmanız gerekir.

- 1 DREO'yu başlatın ve uygulama içi talimatları izleyerek oturum açın veya hesap oluşturun.
- 2 Mobil cihazınızda Bluetooth'u etkinleştirin ve cihazınızı takın.
- 3 WiFi bağlantı ayarlarını başlatmak için (A) tuşunu 5 saniye basılı tutun. (İpucu: WiFi simgesi ̶ eşleştirme sırasında yanıp sönmeye devam edecektir.)
- 4 + **Cihaz Ekle**'ye dokunun ve **Smart Air Purifier 338S** öğesini seçin.
- 5 WiFi bağlantısını tamamlamak için uygulama içi talimatları izleyin.
- 6 Artık cihazınızda cihazı kontrol etmeye hazırsınız. (İpucu: Bağlantı ayarlarını yeniden başlatmak için (A) tuşuna tekrar 5 saniye basılı tutun)


TEMİZLİK VE BAKIM

04

Filtreyi Değiştirme


Filtre ömrü, hava temizleyicinin çalışma modu, fan hızı, çalışma süresi ve iç mekan hava kalitesine dayalı algoritması tarafından ölçülür. Filtreyi 6-8 ayda bir veya filtre değişim hatırlatıcısı uyarısı verdiğinde değiştirmeniz önerilir.

1




Filtrenin değiştirilmesi gerektiğinde Filtre Değişim Hatırlatıcısı yanıp söner. Hava temizleyiciyi kapatın ve fişini çekin.

2




Kilidi açmak için alt kapağı döndürün ve ardından kapağı çıkarın.

3




Plastik ambalajı çıkarın.

4




Eski filtreyi çıkarın ve ardından yeni filtreyi yerine takın.

5



Alt kapağı saat yönünde döndürerek yerine oturtun (kilitlendiğinde belirgin bir ses duyacaksınız).


6



Dik konuma dönün ve Filtre Değişim Hatırlatıcısı sıfırlamak için bip sesi duyana kadar  düğmesine 5 saniye boyunca uzun basın.


İç ve Dış Temizleme

1




Herhangi bir temizlik ve bakım yapmadan önce hava temizleyicinin fişini çekin.

2



Filtreyi çıkarın ve içini toz vakumuyla temizleyin.


3



Gövdeyi kuru, yumuşak, aşındırıcı olmayan bir bezle silin.

Filtreyi Temizleme


- Optimum kullanım için dış ön filtre yumuşak, kuru bir fırça ile 2-4 haftada bir temizlenebilir.
- Sudan ve nemli alanlardan uzak tutun. Nem küf oluşumuna neden olur.



Aroma Ped Tepsisini Temizleme


HAFTADA BİR ÖNERİLİR

1



Aroma pedi tepsisini çekip çıkarın.

2



Su ile durulayın ve tekrar tabana yerleştirin.

Filtreyle İlgili

Yeni bir filtre nereden satın alabilirim?

Yeni filtre satın almak için lütfen müşteri hizmetlerimizle iletişime geçiniz.

Filtreyi değiştirdim, ancak Filtre Değişim Hatırlatıcısı hala açık.

Filtre Değişim Hatırlatıcısı otomatik olarak sıfırlanmayacaktır. Lütfen hatırlatıcıyı sıfırlamak için  Filtre Sıfırlama düğmesini basılı tutun, gösterge sıfırlandıktan sonra kapanacaktır.

Filtre Değişim Hatırlatıcısı uzun süredir aktif değil.

Filtre ömrünü etkileyebilecek birkaç faktör vardır, bunlar arasında iç mekan hava kalitesi seviyesi, çalışma süresi ve havadaki partikül yoğunluğu bulunur. Odanızın hava kalitesi seviyesi daha iyiye ve/veya hava temizleyicinizi sık kullanmıyorsanız, hatırlatıcının yanması daha uzun sürer.

Kullanımla İlgili

Hava temizleyicim neden çalışmıyor?

Gücün bağlı olup olmadığını, güç kablosunun hasarlı olup olmadığını veya elektrik prizinin çalışıp çalışmadığını kontrol edin.

Hava temizleyicimden gelen hava akışı çok zayıf.

- Hava temizleyicinin etrafında yeterli alan olduğundan emin olun.
- Filtre ambalajının çıkarılıp çıkarılmadığını kontrol edin.
- Otomatik mod açıldığında ve hava kalitesi iyi olduğunda fan hızı düşük olacaktır. Daha yüksek hıza geçmeyi deneyin.
- Filtre tıkalıysa ve aşırı yüklenmişse filtreyi değiştirin.

Hava temizleyicim hava kalitesini iyileştirmiyor.

- Filtre ambalajının çıkarılıp çıkarılmadığını kontrol edin.
- Kirlı hava pencerelerin dışından içeri girmeye devam edebileceğinden pencerelerin kapalı olduğundan emin olun.
- Aşırı yüklenmiş filtre, fanın havayı geçirmek için daha fazla çalışmasına neden olur. Filtre tıkalıysa değiştirmeyi düşünün.
- Kalabalık alanlara ve köşelere yerleştirmeyin.
- Hava çıkışının ve girişinin tıkalı olup olmadığını kontrol edin.

Hava temizleyicim neden yüksek ses çıkarıyor?

- Hava temizleyiciyi uyku moduna veya daha düşük temizleme hızlarına getirin.

Hava Kalitesi göstergesi neden her zaman kırmızı?

- Cihazı farklı bir yere taşımanız, fişini tekrar takmanız ve gösterge ışığını tekrar kontrol etmeniz önerilir. Sorun devam ederse lütfen Müşteri Desteğimize iletişime geçin.

Odadaki koku çok güçlü, ancak Hava Kalitesi Göstergesi yalnızca yeşil veya mavi.

- Hava Kalitesi Sensörü PM 2.5 parçacıklarını algılıyor ancak kokuları algılayamıyor. İç mekan hava kokusunun nispeten güçlü olduğunu düşünüyorsanız, en yüksek arıtma hızını manuel olarak açmanız önerilir.

Hava Kalitesi göstergesi neden her zaman mavi?

- Hava Kalitesi sensörü havadaki partiküllerin varlığını bildirir, ancak gazı algılayamaz. Lütfen odanızın içinde gaz kirliliği olmadığından emin olun.

Hava temizleyicim neden alışılmadık bir ses çıkarıyor?

- Hava temizleyicinin düz ve sabit bir yüzeyde çalıştığından emin olun.
- Olağandışı ses hala devam ediyorsa, hava açıklıklarını tıkayan harici nesneler olabilir. Lütfen müşteri desteğimizle iletişime geçin.

Hava temizleyicim neden hoş olmayan bir koku üretiyor?

- İlk birkaç gün boyunca, yeni hava temizleyiciler normal olan ve sonunda kaybolacak bir plastik kokusu üretir.
- Hava temizleyiciye uçucu yağlar veya difüzörler eklemeyin veya aşırı nemli bir alanda kullanmayın. Nem, küf oluşumuna neden olur.
- Filtre kirleticileri maksimum kapasitesinde emmişse, koku kirli filtreden gelebilir. Lütfen gerektiğinde filtreyi değiştirin.

Sorunuz listelenmemişse veya hala devam ediyorsa, lütfen Müşteri Desteğimizle iletişime geçin (**bkz. sayfa 27**).

Model No.: DR-HAP008S
Rev_TR_1.0

Reach out to us, it's easy!
Bize ulaşın, çok kolay!

 **+49 800 000 9169** Mon-Fri 9:00-12:00 / 14:00-17:00 CEST/UTC+2 (Germany Only)

 **eu-support@dreo.com / uk-support@dreo.com**

 **www.dreo.com**

www.dreo.com

Looking for help? Yardı mı arıyorsunuz?

Contact us to get expert support.
Uzman deste ği için lütfen bizimle irtibata geçin.



eu-support@dreo.com
uk-support@dreo.com



+49 800 000 9169

Mon-Fri 9:00-12:00 / 14:00-17:00
CEST/UTC+2 (Germany Only)



www.dreo.com